

This Technical Note provides guidance on the pins that can be used to fix Erosaweb to a slope, how to install them, the number of pins required, and their layout. This Technical Note does not cover Erosaweb installed over a sensitive membrane, or revetments which may require large stones or concrete infill. These solutions are covered in separate Technical Notes.

### **Pin Type**

The pins used should be specified in the Project drawings. They will either be J Pins or Helical Pins. The type of pin typically used will vary depending on which type of Erosaweb is used on site (see Table 1).




Figure 1: Abpins

Table 1: Pin Types for use with ABG Erosaweb

Pin	Туре	Length	Diameter	ABG Erosaweb Compatibility
Abpin 300/8	J Pin	300 mm	8 mm	GWX 100/300
Abpin 500/8	J Pin	500 mm	8 mm	GWX 200/300
Abpin 700/10	J Pin	700mm	10mm	GWX 300/300
Abpin 200/4 Wide Helix with WebGrip	Helical Pin	200 mm	4 mm	All (soft soil)
Abpin 200/4 Narrow Helix with WebGrip	Helical Pin	200 mm	4 mm	All (stiff soil)

### **Pin Type Selection**

Helical Pins offer several advantages over traditional J Pins: Helical pins provide greater anchorage per pin than J Pins, are faster and easier to install (see below), are significantly lighter than J Pins (which makes them easier to manage on site and reduces the carbon footprint of the installation), and give a better aesthetic finish as there is no hook at the finished surface level. However, Helical pins are more expensive per pin than J Pins. The ABG Sales Team can be contacted for further advice on the most suitable pin for each project.

#### Pin Installation

J Pins are hammered into the slope using a mallet and are installed at the apex of the Erosaweb cell with the hook looped over the top of the cell wall (see Figure 2a). Helical pins are drilled into the slope with a standard hand drill and the supplied custom chuck (see Figure 2b). They are installed into the sides of the Erosaweb cells with the Webgrip hooked into the perforations of the Erosaweb. All pins should be installed at approx. 10° off perpendicular to the slope as shown in Figure 2.




Figure 2: Pin Installation



### **Pin Layout**

The layout of pins across an Erosaweb panel can be difficult to translate from a specification to practical application on site. In addition, the layout will vary depending on the slope angle and soil conditions, and the type of pin used (J pin or Helical Pin). Appended to this document are diagrams illustrating the pin layout for each of the following situations:

- Erosaweb 300 J Pin Layout
- Erosaweb 300 Helical Pin Layout

These diagrams are collectively referred to as the 'Erosaweb Pin Layout Diagrams' and should be read in conjunction with the advice in this Technical Note.

### **Pin Frequency**

As with the pin layout, the frequency of pins varies depending on the slope angle and soil conditions, the type of pin used and the type of Erosaweb. The total quantity of pins required will depend on the number of 'Intermediate Pins' (pins dispersed evenly across the slope) and 'Panel Connection and Edge Pins' (pins located between Erosaweb panels and at the edges of the slope).

### **Intermediate Pins**

The number of Intermediate Pins required is specified as a 'Pinning Pattern' which matches the size of the Erosaweb cells, and on a per m<sup>2</sup> basis to quickly assess quantities. Table 2 lists typical Intermediate Pin frequencies for average ground conditions and the Pinning Pattern to use in accordance with the Erosaweb Pin Layout Diagrams. For site specific advice the ABG Technical Team should be contacted for recommendations.

## **Panel Connection and Edge Pins**

Additional Panel Connection Pins are often required where Erosaweb panels abut (Connection Pins) and at the edges of Erosaweb slopes (Edge Pins). Further details on this are contained in the Erosaweb Installation Guide. Both Connection Pins and Edge Pins should be the same type of pin as used for intermediate pinning.

#### Connection Pins

The location and frequency of connection pins is described diagrammatically in the Erosaweb Pin Layout Diagrams. When pinning in the downslope direction where Erosaweb Panels abut, adjacent panels should have their cells nested together with pins connecting the cell walls. When pinning across the slope adjacent panels should be in contact at cell edges only.

If a cell already has a pin in it as part of the Intermediate Pinning regime, an additional connection pin is not required. For example, if Intermediate Pins in Erosaweb 300 are at a rate of 18 per m<sup>2</sup> then every cell already has a pin in it and no Connection Pins are required. If intermediate pins in Erosaweb 500 are at a rate of 2 per m<sup>2</sup> (one in every fourth cell) then Connection Pins are required across the slope, but not required down the slope.

When using J Pins, the hook of the J Pin should extend over into the adjacent panel. When using Helical Pins, the Webgrips should extend through the perforations of both abutting panels (see Erosaweb Pin Layout Diagrams).

### **Edge Pins**

At the top, bottom, and sides of a slope covered in Erosaweb, the Erosaweb should be buried in trenches along each side. Additional Edge Pins should be installed at the base of each trench. At the top of the slope there should be a pin in every cell. Along the sides of the slope Edge Pins should be in every third cell (similar to Panel Connection Pins in the downslope direction). At the bottom of the slope Edge Pins are only required to help expand the Erosaweb panel prior to backfilling – so every 1.5m to 2.0m should be adequate.



### **Table 2: Typical Pin Frequencies**

Erosaweb	Pin Type	Slope ≤ 1:2 (≤26°)	Slope >1:2 to ≤1:1 (>26° to ≤45°)	Slope >1:1 to ≤2:1 (>45° to ≤65°)	
	J Pins				
GWX 100/300	Abpin 300/8	2 pins/m² (Pattern P3-8)	6 pins/m² (Pattern P3-4)	9 pins/m² (Pattern P3-3)	
GWX 150/300	Abpin 400/8	3 pins/m² (Pattern P3-6)	9 pins/m² (Pattern P3-3)	14 pins/m² (Pattern P3-2)	
GWX 200/300	Abpin 500/8	5 pins/m² (Pattern P3-5)	9 pins/m² (Pattern P3-3)	14 pins/m² (Pattern P3-2)	
GWX 300/300	Abpin 700/10	5 pins/m² (Pattern P3-5)	9 pins/m <sup>2</sup> (Pattern P3-3)	14 pins/m² (Pattern P3-2)	

The frequencies shown above include additional pins for connecting adjacent panels, and edge pins.

	Helical Pins with Webgrip	(HW)		
GWX 100/300	Abpin 200/4HW	2 pins/m² (Pattern P3-8)	3 pins/m² (Pattern P3-6)	5 pins/m² (Pattern P3-5)
GWX 150/300	Abpin 200/4HW	2 pins/m <sup>2</sup> (Pattern P3-8)	5 pins/m² (Pattern P3-5)	6 pins/m² (Pattern P3-4)
GWX 200/300	Abpin 200/4HW	2 pins/m <sup>2</sup> (Pattern P3-7)	6 pins/m² (Pattern P3-4)	9 pins/m² (Pattern P3-3)
GWX 300/300	Abpin 200/4HW	3 pins/m <sup>2</sup> (Pattern P3-6)	9 pins/m <sup>2</sup> (Pattern P3-3)	14 pins/m² (Pattern P3-2)

The Helical Pin frequencies shown above do not include for connecting adjacent panels. Additional cable ties are required to connect adjacent panels at a rate of 18 or 22 ties per Erosaweb panel.


### Notes:

- 1. The pinning frequencies outlined above should be used for budget pricing only. Contact Technical for advice before finalising the design. Particularly for slopes not specifically equal to 1:2, 1:1, or 2:1, more economic pin spacings than those outlined above can be achieved.
- On slopes steeper than 45° Erosaweb will be suitable provided the cells are filled with suitably cohesive fill to ensure the soil is contained within the Erosaweb cells. If cohesive soil is not available, contact ABG for alternative soil retention solutions.
- The final spacing of Intermediate Pins is heavily dependent on the ground conditions on site. As such the values given above are indicative only and no guarantee is given that they are accurate for all sites.
- Intermediate Pin spacings are based on pins installed in average ground conditions, backfilled with typical topsoil. Spacings may be reduced if pins are to be installed in firmer ground and test pin installation shows improved performance. If poor ground conditions exist the ABG Technical Team must be contacted to provide site specific advice.
- 5. Further information on the Erosaweb installation process is provided in the Erosaweb Installation Guide.



## J Pin - Pinning Patterns


Pattern Name	Pins per m²	Distributio	n			Pattern Name	Pins per m²	Distributio	n		
P3-1	18	a: 1/1	<b>b</b> : 1/1	<b>c</b> : 1/1	<mark>d</mark> : 1/1	P3-5	5	<b>a</b> : 1/2	<b>b</b> : 0	<b>c</b> : 1/2 [O]	<b>d</b> : 0
P3-2	14	a: 1/1	<b>b</b> : 1/2	<b>c</b> :1/1	d: 1/2 [O]	P3-6	3	<b>a</b> : 1/3	<b>b</b> : 1/3	<b>c</b> : 0	<b>d</b> : 0
P3-3	9	a: 1/1	<b>b</b> : 0	<b>c</b> : 1/1	<b>d</b> : 0	P3-7	2	<b>a</b> : 1/4	<b>b</b> : 0	<b>c</b> : 1/4 [O]	<b>d</b> : 0
P3-4	6	<b>a</b> : 2/3	<b>b</b> : 0	<b>c</b> : 2/3 [O]	<b>d</b> : 0	P3-8	2	<b>a</b> : 1/5	<b>b</b> : 1/5 [O]	<b>c</b> : 0	<b>d</b> : 0




#### **Additional Pins at Slope Edges**

At the top, bottom, and sides of the slope the Erosaweb should be buried in a trench with additional pins at the base of the trench.

Trench Location	Pins at Base of Trench
Top of Slope	One pin per cell
Slope Sides	One pin in every third cell
Base of Slope	As required to hold cells in place prior to backfilling








#### Notes:

 $1. \quad \text{The pins shown in the figures are not to scale}.$ 































## **Helical Pins – Pinning Patterns**

Pattern Name	Pins per m²	Distributio	n			Pattern Name	Pins per m²	Distributio	n		
P3-1	18	a: 1/1	<b>b</b> : 1/1	<b>c</b> : 1/1	d: 1/1	P3-5	5	a: 1/2	<b>b</b> : 0	<b>c</b> : 1/2 [O]	<b>d</b> : 0
P3-2	14	a: 1/1	<b>b</b> : 1/2	<b>c</b> :1/1	d: 1/2 [O]	P3-6	3	<b>a</b> : 1/3	<b>b</b> : 1/3 [O]	<b>c</b> : 0	<b>d</b> : 0
P3-3	9	a: 1/1	<b>b</b> : 0	<b>c</b> : 1/1	d: 0	P3-7	2	a: 1/4	<b>b</b> : 0	<b>c</b> : 1/4 [O]	d: 0
P3-4	6	<b>a</b> : 2/3	<b>b</b> : 0	<b>c</b> : 2/3 [O]	<b>d</b> : 0	P3-8	2	<b>a</b> : 1/5	<b>b</b> : 1/5 [O]	<b>c</b> : 0	<b>d</b> : 0

#### **General Pin Installation Guide**




### **Additional Pins at Slope Edges**

At the top, bottom, and sides of the slope the Erosaweb should be buried in a trench with additional pins at the base of the trench.

Trench Location	Pins at Base of Trench
Top of Slope	One pin per cell
Slope Sides	One pin in every third cell
Base of Slope	As required to hold cells in place prior to backfilling

### **Additional Panel Connection Pins**



(Pinning in the downslope direction)

